

INSTALLATION INSTRUCTIONS FOR 1999-2004 FORD 4WD SUPER DUTY 6" SUSPENSION SYSTEM

Requires the following parts (sold separately) for a complete installation:

- Front Leaf Springs P/N 60SD6
- Hardware Kit P/N 6000H
- Vehicle specific Box Kit depending on vehicle date of manufacture:
 - MANUFACTURE DATE PRIOR TO 3/99 P/N 6061B
 - MANUFACTURE DATE 3/1/99 TO 4/1/99 P/N 6062B
 - MANUFACTURE DATE 4/2/99 TO 12/31/99 P/N 6063B
 - MANUFACTURE DATE AFTER 12/31/99 P/N 6064B

WARNING!!! READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE PROCEEDING. MAKE SURE THAT YOU HAVE ALL TOOLS AND PARTS BEFORE BEGINNING THE INSTALLATION.

SPECIAL ITEMS REQUIRED:

- STEERING (PITMAN) ARM PULLER
- TIE ROD SEPARATING TOOL
- TORQUE WRENCH
- FORD SERVICE MANUAL

REVTEK INDUSTRIES RECOMMENDS THAT RED LOCTITE BE USED ON ALL FASTENERS UNLESS OTHERWISE NOTED. IT IS ALSO RECOMMENDED TO HAVE THE FRONT END ALIGNMENT CHECKED AFTER INSTALLATION.

GENERAL NOTES:

- 1. THIS SYSTEM SHOULD ONLY BE INSTALLED BY A PROFESSIONAL MECHANIC.
- 2. Compare all contents of the boxes to the parts list before starting to insure all components are included.
- 3. Prior to installing the suspension system, inspect the vehicle's suspension components, alignment, and frame for damage, corrosion, or cracks. Correct any worn or damaged parts before beginning install.
- 4. Always wear safety glasses during installation
- 5. On most vehicles, removal of the front bumper may be necessary in order to remove front spring eye bolts.
- 6. Install all nuts and bolts with a flat washer on both sides.
- 7. Unless otherwise noted, tighten all bolts to the torque specifications listed in the Torque Specification table included in these instructions. Use a torque wrench.
- 8. Estimated time to install this system is 6 hours.
- 9. Suspension components that use rubber or urethane bushings should be tightened with the vehicle at normal ride height. This will prevent premature failure of the bushing and maintain ride comfort
- 10. Check off the step number at the beginning of each step when you finish it. Then when you stop during the installation, it will be easier to find where you need to continue from.

09/10/08 Pg 1 of 7

KIT CONTENTS INCLUDE:

- Instructions including parts list
- Product Safety Label (orange)
- Decal
- Warranty Information

PARTS LIST INCLUDED IN KIT

 $\frac{\text{PART \#}}{\text{6" SUPER DUTY FRONT SPRING}} \qquad \frac{\text{OTY}}{\text{60SD6}}.$

HARDWARE KIT - 6000H

REAR 5" CAST BLOCKS	CB-5SD	2
REAR 5/8 X 3 5/8 X 16 U-BOLTS	R53816B	4
5/8" HIGH NUT	R58HNB	8
5/8" FLAT WASHER	R58FWB	8
½" FLAT WASHER	R12FWZ	8
½"-13 NYLON INSERT LOCKNUT (ZINC)	R128NZ	4
4.5" POLY BUMP STOP	BS45F	2
3/8" – 16 NYLON INSERT LOCKNUT (ZINC)	R38NLZ	2
3/8" FLAT WASHER	R38FWZ	2
CARRIER BEARING DROP BRACKET	RCB34D	1
½ - 13 X 2" GRADE 8 BOLTS (ZINC)	R2128Z	4
REAR SHOCKS	R3319	2

	STANDA	RD BOLT TO	ORQUE & I	DENTIFICA	ATION	
	INCH SYSTEM	[-	METRIC	SYSTEM	
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 9.8	Class 10.9	Class 12.9
5/16	15 ft. lbs.	20 ft. lbs.	M6	5 ft. lbs.	9 ft. lbs.	12 ft. lbs.
3/8	30 ft. lbs.	35 ft. lbs.	M8	18 ft. lbs.	23 ft. lbs.	27 ft. lbs.
7/16	45 ft. lbs.	60 ft. lbs.	M10	32 ft. lbs.	45 ft. lbs.	50 ft. lbs.
1/2	65 ft. lbs.	90 ft. lbs.	M12	55 ft. lbs.	75 ft. lbs.	90 ft. lbs.
9/16	95 ft. lbs.	130 ft. lbs.	M14	85 ft. lbs.	120 ft. lbs.	145 ft. lbs.
5/8	135 ft. lbs.	175 ft. lbs.	M16	130 ft. lbs.	165 ft. lbs.	210 ft. lbs.
3/4	185 ft. lbs.	280 ft. lbs.	M18	170 ft. lbs.	240 ft. lbs.	290 ft. lbs.
1/2-13x1.75 HHCS						
G= Grade Marking (bolt strength) L= Length (inches) D= Nominal Diameter (inches) X= Description (hex head cap screw) T= Thread Pitch (threads per inch) P= Property Class (bolt strength) L= Length (millimeters) D= Nominal Diameter (millimeters) T= Thread Pitch (thread width, mm)		rew)				

09/10/08 Pg 2 of 7

VEHICLE SPECIFIC BOX KITS – BOX 1 of 2

6061B – UP TO 2/28/99	PART #	QTY
PITMAN ARM (FD400)	P400	1
1/2 - 13 GRADE C ALL METAL	R12CMLZ	1
LOCKNUT		
½" FLAT WASHER	R12FWZ	2
1/2 - 13 X 3 1/4 HEX GRADE 8 BOLT	R314128Z	1
(ZINC)		
9/16 - 12 X 3 ½ GRADE 8 HEX	R3159168Z	1
BOLT (ZINC)		
7/16 - 14 X 3 ¼ GRADE 8 ZINC	R7163148Z	2
BOLT		
7/16 FLAT WASHER (SAE)	R716FWZ	2
9/16 – 12 GRADE C ALL METAL TOP	R916CMLZ	1
LOCKNUT (ZINC)		
9/16 FLAT WASHER	R916FWB	8
9/16 FLAT WASHER (ZINC)	R916FWZ	2
9/16 HIGH NUT	R916HNB	8
9/16 X 3 1/8 X 9 SQUARE TOP U-	R9389STB	4
BOLT		
CARRIER BEARING DROP BRACKET	RCB34D	1
6" TRACK BAR BRACKET - SM HOLE	TSD16	1
SHOCKS	R3319	2

6063B - 4/1/99 TO 12/31/99 WITH

PART #	QTY
P500	1
R12CMLZ	1
R12FWZ	2
R314128Z	1
R7163148Z	2
R716FWZ	2
R916FWB	8
R916HNB	8
R9389STB	4
RCB34D	1
RSWB1	2
TSD26	1
R3319	2
	P500 R12CMLZ R12FWZ R314128Z R7163148Z R716FWZ R916FWB R916HNB R9389STB RCB34D RSWB1 TSD26

6062B – 3/1/99 TO 4/1/99 WITH SQUARE FRONT U-BOLTS

SQUINE I NOTITE BOLIS		
PITMAN ARM (FD400)	P400	1
1/2 - 13 GRADE C ALL METAL	R12CMLZ	1
LOCKNUT (ZINC)		
1/2" FLAT WASHER (ZINC)	R12FWZ	2
1/2 - 13 X 3 1/4 HEX GRADE 8 BOLT	R314128Z	1
(ZINC)		
7/16 - 14 X 3 ¼ GRADE 8 ZINC	R7163148Z	2
BOLT		
7/16 FLAT WASHER (SAE)	R716FWZ	2
9/16 FLAT WASHER	R916FWB	8
9/16 HIGH NUT	R916HNB	8
9/16 X 3 1/8 X 9 SQUARE TOP U-	R9389STB	4
BOLT		
CARRIER BEARING DROP BRACKET	RCB34D	1
SWAY BAR SUPPORT BRACKETS	RSWB1	2
6" TRACK BAR BRACKET LG HOLE	TSD26	1
SHOCKS	R3319	2
-		

6064B – 4/1/99 - 2004 WITH SEMI ROUND FRONT U-BOLTS

ROUND FROM I O-DOLLS		
PITMAN ARM (FD500)	P500	1
1/2 - 13 GRADE C ALL METAL	R12CMLZ	1
LOCKNUT (ZINC)		
½' FLAT WASHER (ZINC)	R12FWZ	2
1/2 - 13 X 3 1/4 GRADE 8 HEX BOLT	R314128Z	1
(ZINC)		
7/16 - 14 X 3 ¼ GRADE 8 ZINC	R7163148Z	2
BOLT		
7/16 FLAT WASHER (SAE)	R716FWZ	2
9/16 HIGH NUT	R916HNB	8
9/16 X 3 1/8 X 9" SEMI ROUND U-	R9389SRTB	4
BOLT		
CARRIER BEARING DROP BRACKET	RCB34D	1
SWAY BAR SUPPORT BRACKETS	RSWB1	2
6" TRACK ARM BRACKET – LG HOLE	TSD26	1
SHOCKS	R3319	2
9/16 X 3 1/8 X 9" SEMI ROUND U- BOLT CARRIER BEARING DROP BRACKET SWAY BAR SUPPORT BRACKETS 6" TRACK ARM BRACKET – LG HOLE	R9389SRTB RCB34D RSWB1 TSD26	1 2 1


BOX 2 OF 2 FOR ALL VEHICLE BOX KITS INCLUDE:


2" ADD-A-LEAF	AAL6020	1 PAIR
CENTER PIN	A6020PIN	1 PAIR
CENTER PIN NUT	A6020NUT	1 PAIR

09/10/08 Pg 3 of 7

FRONT OF VEHICLE - DISASSEMBLY AND ASSEMBLY

- 1. Park vehicle on level, hard (concrete) surface.
- 2. Block the rear wheels of the vehicle to prevent vehicle from moving in either direction and set parking brake.
- 3. Remove front bumper by removing (2) outer 13mm brace bolts and the (4) 18mm bolts from front of bumper.
 - If the vehicle contains a crash bar below the bumper, it must be removed. To accomplish this, remove the (6) 21mm nuts.
 - While supporting the bumper, disconnect the (2) lighting harness plugs and wiring harness from bumper, and the 3 plastic push clips in the rubber shield. Carefully remove bumper, making sure not to scratch the paint on the front fenders.





- 6. Raise the front of vehicle and support with jack stands on the frame behind the front springs.
- 7. Remove the front wheels.
- 8. Support the front axle with a floor jack.
- 9. Remove sway bar end links on both sides. Save the 15mm bolts, to use for reassembly.
- 10. Remove front shocks (saving bolts for reinstallation).
- 11. Remove stock bump stops.
- 12. Carefully bend brake line bracket at frame to horizontal position (see illustration 3).
- 13. While supporting front differential with a floor jack, remove driver side U-bolts.

TECH TIP: Factory spring bolts are secured with loctite, which makes removal difficult. By warming the nut with a propane torch to approx. 300 degrees Fahrenheit, the loctite will release and the hardware can be removed with hand tools. (WARNING: Have Fire Extinguisher handy whenever using a open flame on or near any vehicle.)



Illustration 1



Illustration 2



Illustration 3

- 14. Remove front driver side leaf spring front nuts (27mm) and rear nuts (21mm), leaving spring eye bolts in place.
- 15. Lower axle to clear spring. Remove spring bolts and spring.
- 16. Install new Revtek spring using existing hardware. DO NOT TIGHTEN.
- 17. Raise axle to spring and secure with new 9/16" U-bolts and nuts supplied, making sure center pin is seated properly.

09/10/08 Pg 4 of 7

FRONT OF VEHICLE – DISASSEMBLY AND ASSEMBLY (Continued)

18. Repeat steps 14 - 17 on passenger side.

TECH TIP: The two 15mm bolts are secured with loctite, which makes removal difficult. By warming the nut with a propane torch to approx. 300 degrees Fahrenheit, the loctite will release and the hardware can be removed with hand tools. (WARNING: Have Fire Extinguisher handy whenever using a open flame on or near any vehicle.)

- 19. Remove OEM cast track bar bracket on driver side. Save the (2) 15mm bolts for later reuse.
- 20. Use a pitman arm puller to remove the pitman arm.
- 21. Install new pitman arm using red loctite. Torque to 185 ft./lbs.
- 22. Install Revtek track bar bracket. Use existing bolts and pal nuts on frame and use new ½"x 3 ¼" bolt in crossmember. Install ½" bolt from front of vehicle and use flat washers under head of bolt and nut. Torque bolts to 90 ft./lbs.
- 23. Install new bump stops with 3/8" nuts and washers provided, using single mounting hole directly above axle tube (both sides).

NOTE: On early 1999 vehicles (up to 2/28/99), the sway bar brackets are already located below the frame. On these vehicles, finish the installation after the vehicle is lowered to the ground and bolt up existing end links.

24. Remove upper sway bar mounts from inside of frame on both sides. Relocate under frame using OEM hardware (see illustration 4). Install provided sway bar support brackets, using ½" x 2" bolts, nuts and washers. Torque to


specs. (DOES NOT APPLY TO VEHICLES USING BOX KIT 6001B.)

25. Install new Revtek shocks, P/N R3319, and torque mounting hardware to specs.

- 26. Install drag link to pitman arm utilizing new cotter pin and torque to specs.
- 27. Install tires. Set vehicle on ground and torque wheels to factory specs.
- 28. Install sway bar end links using OEM hardware.
- 29. Tighten spring eye mounting bolts. Torque 18mm spring bolts to 130 ft./lbs. and 16mm spring bolts to 115 ft./lbs.
- 30. Install track bar into new mount (new 9/16" x 3 ½" bolt nut and washers on vehicles up to 3/1/99) and OEM 30mm bolt for vehicles produced after 3/2/99. Torque to 135 ft./lbs.

TECH TIP: Turning steering slightly will help align bolt.

31. If bumper was removed, reinstall air conditioning cooler supports and then reinstall bumper by reversing steps 3 and 4, then torque to spec.



09/10/08 Pg 5 of 7

REAR OF VEHICLE - DISASSEMBLY AND ASSEMBLY

- 1. Block front wheels to prevent vehicle from moving in either direction.
- 2. Lift the vehicle from the center of the rear differential housing, leaving the jack in place to support the differential.
- 3. Support the frame with jack stands forward of the rear springs.
- 4. Remove rear wheels and shocks.
- 5. Remove the U-bolts and anchor plate on driver side only.
- 6. Carefully bend brake line bracket down at frame and relocate vent tube clip to lower part of frame.
- 7. Carefully lower the floor jack, while watching for brake line extension.
- 8. Loosen the nut on the bolt holding the shackle to the spring. Remove the shackle to rear bracket bolt and the spring to front bracket bolt. Remove the spring assembly from the vehicle.
- 9. Clamp the spring assembly securely together with two C-clamps or a large bench vise.
- 10. Loosen the nut and remove the center bolt. If necessary, hold the head of the center bolt with locking pliers. Do not remove the spring clips, but the forward spring clip will need to be opened up.
- 11. Carefully remove the C-clamps or loosen the vise.

NOTE: Removing and installing a leaf may require the use of a soft mallet, and lightly clamping sections of the spring pack to relieve binding.

- 12. Insert the new leaf into the spring pack, placing it below #2 leaf.
- 13. Center the leaves and align the center holes with a drift punch. Reposition the helper spring and install the NEW center bolt and nut with the pin side at the bottom of spring pack.
- 14. Reinstall the C-clamps, or use a vise, to squeeze the spring pack. Tighten the center bolt to 20 ft-lbs and cut off excess threads.
- 15. Reinstall the spring assembly (shackle in the rear) and loosely attached it to the frame brackets with the original hardware. Align the center bolt with the hole in the new 5" lift block, making sure that the small end of taper on the block faces toward the front of the vehicle. (**NOTE**: The realignment of center pin may require slight loosening of opposite side u-bolts.)
- 16. Install the anchor plate and the new U-bolt hardware. Torque U-bolts to specs.
- 17. Repeat steps 5 through 16 for the other side.
- 18. Install Revtek shocks P/N R3319 and torque hardware to specs.
- 19. Cut off excess u-bolt to prevent body damage, if applicable.
- 20. Install tires and lower vehicle to ground. Torque wheels to factory specs.
- 21. Tighten both front and rear spring pivot bolts, and the shackle bolts to 80 ft-lbs.
- 22. Install (2) carrier bearing drop brackets with supplied 7/16 x 3 ¹/₄" bolt and washers. (**NOTE**: Some vehicles may require major driveshaft modifications to correct vibrations.)

23	CHECKS	AND	ADJUSTN	MFNTS
∠J.	CHECKS	$\Delta \mathbf{U}$	ADJUSIN	MENTO.

Check all hardware for tightness after 100 miles and after off road use.
Headlights should be adjusted.
☐ Vehicle must be aligned.

PRODUCT SAFETY LABEL MUST BE INSTALLED INSIDE CAB IN PLAIN VIEW OF ALL OCCUPANTS

09/10/08 Pg 6 of 7

Limited Lifetime Warranty

Revtek Industries products are warranted to be free from material and workmanship defects for as long as the original retail purchaser owns the vehicle upon which such products were originally installed (proof of purchase required). The consumer will be responsible for removing from the vehicle and returning any defective item, freight prepaid, and for reinstallation. This warranty is non-transferable. Revtek Industries' limit of liability under this warranty is to repair or replace the product at Revtek Industries' option. Consequential costs such as, but not limited to labor fees, loss of use, loss of time or freight charges are not covered. Any product that has been abused, altered, incorrectly installed, or used in competition is not covered. Product finish is excluded from this warranty. Items that are subject to wear are not considered defective when worn and are not covered. The warranty is void if the "Warning to Driver" decal is not properly displayed on the vehicle. No other warranties are expressed or implied. We reserve the right to make changes in design, materials, and specifications without prior notice.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. Some states do no allow limitations on how long an implied warranty lasts or allow the exclusion or limitation of incidental or consequential damages, the above limitation or exclusion may not apply to you.

There are no warranties, expressed or implied including any implied warranties of merchantability and fitness, which extend beyond this warranty period. There are no warranties that extend beyond the face hereof. Seller disclaims implied warranty of merchantability.

This warranty shall not apply to any product which has been improperly installed, modified or customized. Warranty does not apply to any components used for racing purposes or racing type activities.

To make a claim under this warranty contact Revtek Industries about the problem prior to removing any parts from the vehicle. If it appears that the part is warrantable, you will be given a Return Authorization (RA) number and asked to return the part freight prepaid. If the part is found to be warrantable, it will be repaired or replaced and returned to you. All freight charges are the customer's responsibility. If a replacement part is needed before the part in question can be returned, you must first purchase the replacement part. Then, if the part in question is deemed warrantable, you will be credited / refunded.



REVTEK INDUSTRIES, LLC 4288 SE International Way Portland OR 97222 1-877-543-8869 / 503-659-1650

09/10/08 Pg 7 of 7